

# **MWC ANTI ROLL BAR DIRECTIONS**

**SET DRIVERS SIDE HEIM JOINTS TO THREE THREADS PAST JAMB NUTS & TIGHTEN.**

**WITH DRIVER IN THE VEHICLE AND ALL FOUR TIRE PRESSURES SET ESTABLISH A NEUTRAL LOAD POSITION WITH PASSENGER LINK & THEN LENGTHEN PASS SIDE LINK A 1/2 TURN. TIGHTEN PASSENGER SIDE JAMB NUTS.**

**PARTS TO THE KIT AS FOLLOWS.**

- (1) MWC ARB**
- (2) END LINKS**
- (2) CHASSIS TABS**
- (2) RIGHT HAND HEIM JOINTS**
- (2) LEFT HAND HEIM JOINTS**
- (2) RIGHT HAND JAM NUTS**
- (2) LEFT HAND JAM NUTS**
- (4) 3/8 X 1 1/4 BOLTS**
- (4) 3/8 JAM NUTS**

**DUE TO THE VARIATIONS ENCOUNTERED IN THE USE & INSTALLATION OF RACING EQUIPMENT, AND THE EXTREME CONDITIONS & STRESSES PLACED UPON SUCH PRODUCTS, NO WARRANTY OF ANY KIND IS GIVEN, NOR ANY REPRESENTATION MADE WITH OUR PRODUCTS. WE SPECIFICLY DISCLAIM ANY RESPONSIBILITY OR LIABILITY FOR DAMAGES, EITHER DIRECT OR CONSEQUENTIAL, AS A RESULT OF THE USE OF OUR PRODUCT.**